

RFID (unattended scale card system) - Instructions

Corn Customers

1. To ensure accurate weight, please un-tarp prior to pulling on scale
2. Drive up to Scale House
3. Scan Card
4. Scale takes first/gross weight
5. Scale Master probes for sample and grades sample
6. Scale Master signals you to go drop off corn
7. Drop off corn in grains building
8. Drive to outbound scale
9. Scan Card
10. Scale takes final/tare weight
11. Printer prints ticket
12. Select Reprint button if second copy is needed
13. Use intercom if you run into issues

MESSAGE DISPLAY

**IINBOUND &
OUTBOUND KIOSK**


INTERCOM – push button to
call



REPRINT – allows you to print
another copy of your ticket



TICKET PRINTER



SIGNATURE PAD – for future
use on outbound feed loads,
allows you to capture a digital
signature